



EV GUARDIAN SECURITY SYSTEM

OPERATING INSTRUCTIONS

To deter theft of your **EV WARRIOR™**, a sophisticated electronic inter-lock system has been designed to prevent the thumb throttle from operating unless activated by your Guardian transmitter.

To Deactivate the Throttle

When you turn off main power by pushing the power switch to the OFF position located on the right hand side of the handlebar, the Guardian Security System automatically activates. Should someone attempt to push the power switch on without using the Guardian transmitter, the switch will light up, but the thumb throttle remains inoperative. Your **EV WARRIOR™** is deactivated.

To Activate the Throttle

- A) Push the power switch to the ON position.
- B) Press button No. 2 on your Guardian transmitter. A beep will sound which confirms the power has been restored to the throttle. Your **EV WARRIOR™** is now ready for operation.

Your Guardian transmitter is equipped with a long life battery. It is advisable to install a fresh one every year to avoid unexpected battery failure.

To replace the battery, unscrew the back cover and install the new battery with the + and - symbols matching the corresponding symbols on the case. Replace the cover and tighten the screw. A fresh battery has a transmitting range of approximately ten feet.

Remember, the Guardian Security System is designed as a theft deterrent device. It is recommended, however, that you should secure your **EV WARRIOR™** to a fixed object using a bicycle locking device.

The Guardian transmitter is equipped with an extra button that allows you to operate optional receivers to activate electronic garage door openers, gates, exterior lights, audible alarms, etc. See your **EV WARRIOR™** dealer for additional details.

If for any reason your Guardian Security System should malfunction, the manual pedal operation of your **EV WARRIOR™** will not be affected. Repairs to your Guardian Security System should **only be performed** by an authorized **EV WARRIOR™** dealer.